M-105H

BRIDGEPORT SERIES I MILLING MACHINE

APRIL 1981

INSTALLATION, OPERATION AND MAINTENANCE

This manual carries additional safety precautions and warnings. Read and observe the entire procedures contained in this manual.



Bridgeport Machines Division of Textron Inc.



TABLE OF CONTENTS

Machine Specifications	2
Milling Head Specifications	3
Uncrating	4
Shortages	4
Cleaning	4
Lifting Machine	5
Placing on Solid Foundation	6
Leveling Machine	6
Handles	6
Connecting Power Supply	6
Alignment of Head	8
Lubrication	8
Adjustment of Table Gib	10
Adjustment of Saddle and Knee Gibs	10
Clamping Table, Saddle and Knee	11
Removing Table	12
Removing Saddle	12
Mounting Vari-Drive Attachment to Ram Adapter	14
Lubrication	14
Operating Instructions	14
Spindle Brake	16
High-Low Range Switch	16
Hi-Neutral-Lo Lever	16
Power Feed Transmission Engagement Crank	17
Quill Feed Selector	17
Feed Reversing Knob	17
Manual Feed	17
Feed Control Lever	18
Quill Feed Handle	18
Quill Stop	18
Micrometer Adjusting Nut	18
Position of Ram	19
Operating Instructions	19
Removing Motor	20
Changing Vari-Drive Belt	22
Changing Timing Belt	23
General Speed Recommendations	24
Parts Identification	25
Basic Machine	26
Leadscrew Assembly	28
J Head Top Housing	30
J Head	32
2J Head Top Housing	36
2J Head Back Gear	38

i

TABLE OF CONTENTS (continued)

	Page
M Head	40
Shaping Attachment	42
6F Longitudinal Power Feed Assembly	44
Metric Conversion Kits	48

LIST OF ILLUSTRATIONS

Figure		Page
1	Principal Dimensions	1
2	Installation Layout	7
3	Head Alignment Y Axis	8
4	Head Alignment X Axis	8
5	Recommended Lubrication	9
6	Saddle/Table Gib	10
7	Saddle-Knee Gib	10
8	Knee-Column Gib	10
9	Longitudinal and Cross Feed Assembly	13
10	2J Milling Attachment	15
11	Motor Removal	21
12	Removing Vari-Drive Belt	21
13	Removing Timing Belt	22
14	Circuit Diagram – Motors	46
15	Circuit Diagram - Power Feed	47

ii



LONGI	TUDINAL TRAY	VEL		TABLE LEN	IGTH		
30 in. 36 in.	. (762mm) . (914mm)		42 in. (1067mm) 48 in. (1219mm)				
	A	В	C	D	Е	F	
MIN.	82 3/16(2088)	51(1295)	8 3/4(222)	0	0	6 3/4(171)	
MAX.	82 3/16(2088)	63(1600)	20 3/4(527)	18-1/2(470)	12(305)	18 3/4 (476)	

NOTE: Metric specifications in parenthesis

Figure 1. Principal Dimensions

MACHINE SPECIFICATIONS

Range

Table travel (X-axis) 36 in. (914mm) 30 in. (762mm) (42" table) (48" table) Saddle travel (Y-axis) 12 in. (305mm) Quill travel 5 in. (127mm) Knee travel (Z-axis manual) 16 in. (406mm) Ram travel 12 in. (305mm) Throat distance (min.) 6-3/4 in. (171mm) (max.) 18-3/4 in. (476mm) Table to spindle nose gage line (min.) 2-1/2 in. (64mm)

750 lbs. (340 kg.)

9 x 42 in.

(229 x 1067mm)

5/8 in. (16mm)

47-1/4 in. (1200mm)

3 on 2-1/2 in. (64mm) centers

Table

Overall sizes

T-Slots

T-Slot size Height above floor (max.)

Max. weight of workpiece

Milling

Feed rate*

Space and weight

Floor area Height Net Weight Shipping weight

Power

Electrical supply-60 Hz., 3 phase

Color

Standard - Bridgeport Gray

*Power optional

9 x 48 in. (229 x 1219mm)

Std. Power FeedHigh Torque Power Feed(X) 3/4-35 ipm(X) 3/8-15 ipm(19-889mm/min.)(9.5-381mm/min.)

7 x 10 ft. (2.1 x 3.1m) 82-1/16 in. (2088mm) 1988 lbs. (900 kg) 2180 lbs. (989 kg)

208/230/460/575V

MILLING HEAD SPECIFICA TIONS

MODEL	"M" HEAD	"J" HEAD	"I" HEAD HI Speed	"2]" [Before 1077]	-21-
Power	.5 HP	1.0 HP	1.5 HP	1.5 HP	2.0 HP
Motor RPM	1200 RPM	1800 RPM	3600 RPM	1800 RPM	1800 RPM
Speed Ranges - RPM LOW HIGH	6 Steps 275 - 4550	8 Steps 8 0 - 325 660 - 2720	8 Steps 160 - 660 1320 - 5440	Stepless 60 - 500 500 - 4200	Stepless 60 - 500 500 - 4200
Quill Travel Quill Diameter	3.5 in (88.9 mm) 2.562 in (65 mm)	5.0 in (127 mm) 3.375 in (86mm)	5.0 in (127 mm) 2.375 in (86 mm)	5.0 in (127 mm) 3.375 in (86 mm)	5.0 in (127 mm) 3.375 in (86 mm)
Spindle Tapers:	#2 Morse #7 B&S B-3	R-8 #30 Q.C. #40	R-8 #30 Q.C. #40	R-8 #30 Q. C.	R-8 #30 Q.C. #40
Spindle Diameter	1.437 in (36.5mm)	1.875 in (48 mm)			
Spindle Feed Rate	Manual	.0015/Rev (.038mm) .003/Rev (.076mm) .005/Rev (.152mm)	.0015/Rev (.038mm) .003/Rev (.076mm) .006/Rev (.152mm)	.0015/Rev (.038mm) .003/Rev (.076mm) .006/Rev (.152mm)	.0015/Rev (.038mm) .003/Rev (.076mm) .005/Rev (.152mm)
Drilling Capacity -Manual Drilling Capacity -Power	.50 in (12.7mm)dia.	.75 in (19 mm) dia. .37 in (9.4mm)dia.	.75 in (19 mm) dia. .37 in (9.4 mm) dia.	.75 in (19mm) dia. .37 in (9.4mm) dia.	.87 in (22mm) dia. .37 in (9.4mm) dia.
Boring Capacity	1.50 in (38mm)dia.	6.0 in (152.4mm)dia.	6.0 in (152.4mm)dia.	6.0 in (152.4mm)dia.	6.0 in (152.4mm)dia.
Milling Capacity	1 6 19 ³ /min (16cc/min)	1.5 In ³ /min (24cc/min	l. 5 tn ³ /min (24cc/min	230 19 ³ /mtn	2.0 tn ³ /mțn
Spindle to Column-Minimum Meximum	7.5 in (190.5 mm) 19 in (483 mm)	6.0 in (152mm) 23.00 in (584mm)	6.0 in (152mm) 23.00 in (584mm)	6.0 in (152mm) 23.00 in (584mm)	(32cc/min) 6.0 in (152mm) 23.00 in (584mm)

BRIDGEPORT SERIES I MILLING MACHINE

UNCRATING

Carefully remove protective crating and skids so that the machine and parts are not marred, scratched or impaired. In the event of damage in transit, communicate AT ONCE with our representative and the transportation company making delivery.

Machine should be lifted by placing a sling under the ram as illustrated on page 5.

'SHORTAGES Check shipment carefully, against the itemized packing list which is included in the parts box. In case of shortages, report them IMMEDIATELY to the representative from whom the machine was purchased, indicating parts not received which have been checked on the packing list.

CLEANING Thoroughly clean protective coating from machine with suitable cleaning solution.

WARNING IT IS NOT RECOMMENDED THAT GASOLINE OR ANY OTHER HIGHLY INFLAMMABLE CLEANING AGENT BE USED.

Do not move the table, saddle, knee or any moveable part until all ways have been well cleaned and lubricated. Then, by hand, move table, saddle and knee to limit stop in one direction. Clean and lubricate exposed ways and then move each unit to the opposite limit stop and similarly clean and lubricate the exposed ways. Loosen bolts to unlock the ram, and move it forward and backward to the full length in order to clean and lubricate.

POSITIONING HEAD UPRIGHT Loosen four locknuts (#157 page 35), pull stop pin (#133 page 26), out to detent and rotate head to vertical position. Proceed with alignment of head as described on page 8. Tighten nuts evenly, using normal pressure. Care should be taken to avoid excessive pressure since this will cause distortion in the quill. Tighten all nuts to 25 ft. lbs. torque-then repeat to 50 ft. lbs.

LIFTING THE MACHINE

Note position of ram and table when lifting with sling.



PLACING ON SOLID FOUNDATION

The column and base are cast in one piece. When setting machine on a concrete foundation, it is advisable to use a little grout (thin mortar) to take care of any unevenness in the concrete as well as to provide a solid foundation at all points.

When setting machine on a floor that has any surface irregularities, shims should be used to correct this condition to the greatest extent possible. See Figure 2 for installation layout.

NOTE IT IS RECOMMENDED THAT THE MACHINE BE SECURED TO THE FLOOR TO PREVENT MOVEMENT OR TIPPING DUE TO OFF-CENTER LOADING.

Before securing machine to floor (i.e. tightening hold down bolts), make certain that all four corners are making contact with the floor after machine is leveled. If above condition is not met, it is possible to twist the column and put a bind into the ways.

LEVELING MACHINE Set machine by leveling the work table lengthwise and crosswise with a precision instrument. After leveling machine, lower the knee and remove protective material from between head and table.

HANDLES When crating, the three ball crank handles are sometimes turned to face the machine. In these cases the handles should be reversed before operating.

CONNECTING POWER SUPPLY To connect the machine to the plant supply, have qualified electrician proceed as follows:

- 1. Check required machine voltage against power supply to ensure that they are compatible.
- 2. Connect machine wiring to power supply making sure connection is in compliance with local safety regulations.
- 3. Check for correct spindle rotation. In the HIGH SPEED range, the spindle should rotate clockwise when viewed from the top of the machine.

NOTE DRUM SWITCH AND HI-NEUTRAL-LO LEVER MUST BE IN HI RANGE.



Figure 2, Installation Layout

ALIGNMENT OF HEAD

In case of precision boring or work of that nature, where it is necessary to have head perfectly square with the table, use method prescribed below. For general milling use, graduations provided on the head are close enough. To set head perfectly square with table, see Figures 3 and 4. This may be done with Ram adapter (#2 page 26) on Ram (#10 page 26), by adjusting Ram adapter through vertical adjusting worm shaft (#8 page 26). Loosen four locknuts (#157 page 34) but leave drag on same for fine adjustment. To square head to table in the longitudinal axis, mount indicator as shown in Figure 4.



Figure 3. Head Alignment Y Axis Figure 4. Head Alignment X Axis

LUBRICATION

Do not operate machine until properly lubricated. Follow the instructions given in Figure 5.



Figure 5. Recommended Lubrication

Way Surfaces – Lead Screws "Sunoco" Waylube #80 or equivalent

B Milling Heads (Spindle Bearings) S.A.E. 10 or 10W Light Oil (none on grease packed heads)

C Motors are greased for life of bearings

ATTACHMENTS: POWER FEED

Oil to sight level with Mobilube No. 46 S.A.E. 140

SHAPING ATTACHMENT Shell Nassa Oil J78 or K79 Socony Gargoyle Vactra Oil (Heavy Medium)

SHAPING ATTACHMENT (Worm drive) Shell Nassa Oil J78 or K79 Socony Cylinder Oil 600W ADJUSTMENT OF TABLE GIB. The table is provided with a full length tapered gib (#43 page 26) in the saddle, and an adjusting screw on the left side. To take up gib, tighten gib adjusting screw (#41 page 26) slightly and repeat until a slight drag is felt when moving the table by hand.



Figure 6. Saddle/Table Gib. (#43 page 26)

ADJUSTMENT OF SADDLE AND KNEE GIBS. A tapered gib (#49 page 26) is used for adjusting the saddle bearing on the knee. This forms a guide for the saddle. To tighten gib, the same principal as described above is used; however, the chip wiper has to be removed first.



SADDLE GIB ADJ, SCREW

Figure 7. Saddle-Knee Gib (#49 page 26)





ADJUSTMENT OF KNEE GIB. Remove chip wiper and adjust screw until smooth movement is attained. CLAMPING TABLE, SADDLE AND KNEE. When milling with longitudinal table feed only, it is advisable to clamp the knee to the column and the saddle to the knee to add rigidity to these members and provide for heavier cuts with a minimum of vibration. The <u>saddle locking lever</u> is located on the left-hand side of saddle.

Excessive pressure can cause slight table bind. Use moderate clamping pressure, as this will hold saddle sufficiently.



The <u>table clamp lever</u> is located on front of saddle and should always be clamped when longitudinal movement is not required.



The knee clamping lever is at the left side of the knee and should be drawn upward to clamp the knee. This is only a tension brake and will not lock the knee completely. Leave clamped at all times unless using knee in operation.



REMOVING TABLE. Remove as follows: ball crank handles, dial holders, bearing brackets. Lead screw will then turn all the way out so it can be removed. When this is accomplished, the table can easily be taken off by sliding it from the saddle. See Figure 9.

REMOVING SADDLE. Follow along the same lines as removing table; however, it is necessary to remove the entire front bracket assembly. Next, remove the cross feed nut bracket which is made accessible by removal of the table. See Figure 9.



Figure 9, Longitudinal and Crossfeed Assembly

ASSEMBLY INSTRUCTIONS FOR MOUNTING 2-J VARIDRIVE ATTACHMENT TO RAM ADAPTER

Lift the attachment. Insert the four tee bolts into the ram adapter and position them to match the bolt holes in the attachment.

Slide the attachment onto the bolts, insert the spacers and washers and secure with the nuts.

Tighten all the nuts with 25 ft. lbs. of torque, and then repeat with 50 ft. lbs.

CAUTION IMPROPER TIGHTENING OF THESE COULD CAUSE A CHOPPY QUILL MOVEMENT

LUBRICATION:

The useful life of this attachment will be determined to a large extent by proper lubrication. Carefully observe the nameplate recommendations and avoid substitutions.

OPERATING INSTRUCTIONS:

SPEED CHANGE HANDWHEEL (16, Figure 10): DO NOT attempt to change spindle RPM unless the motor is running. Dial speeds will only be approximate. Belt wear will cause a slight variation in speeds from what is indicated on the dial.

When tightening or loosening the drawbar (#14 page 38) it is necessary to lock the spindle. To accomplish this, use the spindle brake (3) which is located on the left side of belt housing, turning it either to the right or left until it binds, then raise the quill feed handle (13).

Drawbar (#14 page 38) has 7/16-20 right hand thread and should be tightened with normal amount of pressure using wrench furnished with machine. To loosen collet back off drawbar and if collet does not open immediately give knob on top of drawbar a slight tap. Spindle has non-sticking taper and collet should release readily.



SPINDLE BRAKE (3, Figure 10): Brake lever can be moved in either direction to stop spindle; however, when locking spindle, lever should be moved to right or left and then raised. When brake is worn out it has to be replaced. There are no adjustments to be made.

> CAUTION BE CERTAIN THAT THE SPINDLE BRAKE IS RELEASED BEFORE STARTING THE MOTOR. THIS IS IMPORTANT AS THE MOTOR CAN BE DAMAGED IF SWITCH IS TURNED ON WITH BRAKE IN LOCKED POSITION.

HIGH-LOW RANGE SWITCH (1): This is the motor reversing switch. When the attachment is in direct drive (High Speed) the motor and spindle are turning in the same direction. When the attachment is in "Back Gear" (Low Speed) the spindle would run backwards unless the motor direction is reversed.

The back-gear lever is marked Hi-Lo. This will indicate the proper switch position. They should be alike or the spindle will run backwards.

HI-NEUTRAL-LO LEVER (15): This lever is used to put the attachment into either backgear or direct drive. Rotate the spindle by hand to facilitate meshing of clutch or gears.

<u>Neutral</u> can also be obtained at mid-way position. After a long period of use, the neutral position may cause noise (in neutral only) by allowing the clutch teeth to rub each other.

This can be corrected by loosening set screw (#64 page 36) and reversing the position of the detent plate (#65 page 36).

<u>Neutral</u> is provided to permit free spindle rotation for indicating and set-up work.

In the <u>high</u> speed position (direct drive) the spindle is driven by tapered clutch teeth. If the clutch is not meshed tightly, clutch rattle will be heard. This can be avoided by moving the detent plate upward as the clutches wear. This is also the reason for possible loss of neutral, requiring the reversal of the detent plate.

> CAUTION DO NOT shift Hi-Lo Lever while motor is running.

POWER FEED TRANSMISSION ENGAGEMENT CRANK (4, Figure 10): Engages power feed worm gear. When lever is in right hand hole, the power feed worm gear is engaged. To disengage worm gear, pull knob out and crank handle in clockwise or down direction and move to opposite position.

NOTE

CRANK CANNOT BE SWUNG AROUND IN COUNTER CLOCKWISE DIRECTION; HOWEVER, NO DAMAGE WILL OCCUR IF MOVED IN THIS DIRECTION. TO ENGAGE THE WORM A CLOCKWISE MOVEMENT IS REQUIRED.

CAUTION

POWER FEED WORM GEAR MAY BE ENGAGED WHEN SPINDLE IS ROTATING, HOWEVER, IT SHOULD BE ENGAGED GENTLY TO AVOID DAMAGE TO WORM GEAR. THE WORM GEAR MAY BE DISENGAGED AT ANY TIME. DO NOT USE POWER FEED AT SPEEDS ABOVE 3000 RPM.

IMPORTANT: It is recommended that the Power Feed worm gear be disengaged whenever the power feed is not required. This will avoid unnecessary wear on power feed worm gear.

QUILL FEED SELECTOR (5): This crank is used for selecting the three feeds; .0015", .003" and .006" per revolution. It is shifted by pulling knob out and turning from one position to the other. Feeds are stamped on cover below indentation hole. Feed is more readily engaged when spindle is running.

FEED REVERSE KNOB (7): Position of this knob depends upon direction of spindle rotation. If boring with right hand cutting tools, pull feed handle towards operator until clutch becomes engaged.

Neutral position is between forward and reverse position. It is recommended that the handle be left in neutral position when not in use.

MANUAL FEED HANDWHEEL (6): Feed reversing knob should be in neutral position and feed control lever (8) engaged. Clockwise rotation of handwheel moves quill down. The Manual Feed Handwheel and the Quill Feed Handle may be disengaged by moving them outward about 1/8".

NOTE

The feed control lever must be engaged in order to use manual feed controls. The Quill Feed Handle and Manual Feed Handwheel may be taken off when not in use.

FEED CONTROL LEVER (8): Engages over-load clutch on pinion shaft when positioned left and will stay engaged until either quill stop comes in contact with micrometer adjusting nut, forcing feed control lever to drop out automatically, or released manually by engaging lever to right.

NOTE

The Feed Control Lever is carefully set at plant to disengage automatically when quill stop goes against micrometer adjusting nut or against throw out pin at top. However, if this should go out of adjustment, it may easily be brought back by regulating the socket set screw located at bottom of tripping rod (item no. 144 page 35).

CAUTION

WHEN ADJUSTING THE SOCKET SET SCREW, CHECK AUTOMATIC DISENGAGEMENT IN BOTH DIRECTIONS; THAT IS WITH QUILL-STOP NUT (#161 PAGE 35) AGAINST THE FEED TRIP LEVER (#145 PAGE 35) FOR DOWN POSITION, AND AGAINST REVERSE TRIP BALL LEVER (#183 PAGE 35) FOR THE UP POSITION.

QUILL FEED HANDLE (13): May be removed by simply pulling handle off. It is recommended that handle be disengaged when using power feed.

QUILL STOP KNOB (14): Is used to disengage automatic feed in either direction as well as the setting point for working to given depths.

MICROMETER NUT (11): This nut is used for setting of depths. Each graduation on nut indicates .001" of depth, it reads directly to scale mounted along side of it. Depths may be obtained by setting micrometer nut in conjunction with quill stop.

QUILL LOCK (12): This is a friction quill lock to be used when quill is in stationary position such as milling operations. It is recommended that this lock be used whenever quill movement is not desired. POSITION OF RAM: Can be regulated by loosening two Ram Lock Studs (#119 page 26) on turret (#124 page 26) and pulling the ram (#10 page 26) in or out to desired position.

CAUTION CARE SHOULD BE TAKEN TO LOCK RAM SECURELY AFTER SETTING.

NOTE It is recommended that on heavy milling work, head should be kept as close to column as possible, where maximum rigidity is obtained.

RECOMMENDATIONS:

Use 2, 3, or 4 flute end mills. Eight flute end mills are usually not as satisfactory for general milling. When using shell mills, face mills or any other tooling, proper machining practice should be observed.

Power feed can be used for drills up to 3/8" in diameter. Use manual feed for drills larger than 3/8".

Overload clutch is set at factory to hold up to 200 lbs. down pressure on quill, which will accommodate drills up to 3/8" diameter in mild tool steel.

CAUTION THIS CLUTCH SHOULD NOT BE TAMPERED WITH IN THE FIELD.

OPERATING INSTRUCTIONS

CAUTION DO NOT TRY TO CHANGE SPEED POSITION UNTIL MOTOR IS RUNNING. THIS COULD CAUSE BREAKAGE OF PARTS.

Spindle Speeds are adjusted by turning speed change handwheel (#21 page 36) on the front of the belt housing. There are two ranges shown; 60 to 500 and 500 to 4200.

60 to 500 is obtained through the back-gear drive and is referred to as the low range. To engage the back-gears, use the lever marked Hi-Neutral-Lo on the right rear side of the attachment. Move this lever to the "LO" position and use the low range on the down switch.

When shifting to "LO," DO NOT FORCE THE LEVER if the back gears do not mesh. Hold the lever so that the gears are clear of one another, rotate the spindle nose by hand until the gears line up, then put the unit in "LO" (back gear) 500 to 4200 is obtained through direct drive and is the high range. The same lever and switch as above are used; selecting the "HI" range.

When shifting to "Hi," do not force the lever if the clutch teeth do not mesh. It is a simple matter to engage the brake and rotate the spindle nose by hand until the clutches engage.

Wear on the vari-drive belt will cause a slight change in the speeds to that shown in windows (#22 page 36) on the dial. This can be corrected as follows. Crank the speed change handwheel (#16, Figure 10) snugly against the high speed stop. (This will be near the 4200 reading on the dial.) Use a tachometer to determine the spindle speed, then turn the pivot stud (#16 page 38), after loosening the jam nut (Item #7 page 38) until the spindle speed registers 4200 on the tachometer; tighten jam nut.

Now reposition the speed dial plate to match the tachometer reading. This is done by loosening the Hex nut (#1 page 36) until the spindle speed registers 4200 on the tachometer; tighten jam nut.

CAUTION TRY TO AVOID SHIFTING THE HI-LO LEVER WHEN THE FEED WORM IS ENGAGED.

DO NOT LOOSEN the 3 hex nuts (#61 page 36) on the upper part of the Quill Housing (#192 page 34). These are set at the factory and are used only for alignment.

SWIVELING THE VARI-DRIVE may be accomplished by loosening the lower 3 hex nuts (#47 page 36) attaching the Vari-Drive unit to the quill housing and then swiveling to any desired position. See arrangement of T-Bolts (#45 page 36) in Gear Housing (#44 page 36) for this purpose.



REMOVING THE MOTOR (See Figure 11): Run the attachment to the bottom of either speed range and shut off the motor. This puts the vari-drive belt in the best position for disassembly.

1. DISCONNECT THE POWER and then remove the switch from the side of the belt housing.

- 2. Remove the cover (#76 page 36) (B, Figure 11) at the lower end of the motor shaft. Use two cover screws (#75 page 36) (A) to fasten the spring (#44 page 38) (C) on the lower end of the motor shaft, to the lower motor vari-drive pulley (#43 page 38). This will reduce the hazard of personal injury that is always present when a heavy spring is under compression. When the pulley, spring retainer (#45 page 38) and spring are securely fastened as a single unit, crank the speed change handwheel (#16 Figure 10) to top speed position.
- 3. Now remove the screws (#9 page 38) (D) that fasten the motor to the belt housing. The motor should be lifted slightly and pulled firmly away from the spindle and toward the rear of the belt housing. This will pull the vari-drive belt (#27 page 38) deeply into the spindle pulley (#25 page 38), providing the slack needed to ship the belt over the motor pulley (#43 page 38).
- 4. Now lift the motor high enough to rest the motor base GENTLY on the adjusting screw (#16 page 38) (E) seen directly in front of the motor flange. The belt can now be slipped over the lower pulley and the motor removed from the housing.



Figure 11. Removing the Motor (Side View)

CHANGING VARI-DRIVE BELT (Figure 12)

Complete the above procedures for removing the motor, then remove the three screws (#1 page 38) (A, Figure 12) and lift out the top bearing cap (#2 page 38) (B). Looking down inside of the housing, locate and remove two socket head cap screws (#17 page 38) and sleeves (#19 page 38) (C). Next, remove the four screws (#6 page 38) (D) and the screw (#55 page 38) (E) holding the belt housing (G) to the base (#53 page 38). Unscrew and remove the two lower screws (#25 page 36) in the speed changer bracket just below the speed dial (#2 page 36) (F).

				NOTE				
On	Mode	ls wit	th plas	tic fac	e plate	(#27	page	36)
ren	love s	screw	s (#23	page	36) firs	st.		



Figure 12. Removing the Vari-Drive Belt

The belt housing, complete with speed changer bracket, is now removed from its belt housing base (#53 page 38). A slight blow under the speed changer bracket (#5 page 36) may be needed to separate the belt housing (#10 page 38) from the belt housing base (#53 page 38).

Remove the old belt (#27 page 38) and replace it with a new belt. DO NOT use a substitute belt purchased from other than a Bridgeport Dealer. Vibration and heat could result from the use of the wrong belt.

CHANGING TIMING BELT (Figure 13)

Complete the operation for removing the motor. Then put the Hi-Neutral-Lo lever (#15, Figure 10) in the Lo position, remove the drawbar (#14 page 38) (A, Figure 13) and lower the spindle.

Remove screws (#55 page 38) (B) hodling the upper and lower housings (#63 page 38) together, including the two lower screws (C) in speed changer bracket just below the speed dial.



Figure 13. Removing Timing Belt

A slight blow under the speed changer bracket (#5 page 36) may be needed to separate the upper housing (D) from its base.

As the housings are being separated, the HTD belt (D) (#36 page 36) still connects them, resisting the separating movement. The separation can be assisted by gently pushing the belt off the large pulley (#86 page 36) as the upper housing is being raised.

Remove the old belt and replace with a new belt.

								Feet F	^p er Minu	te		
	Mate	erial to b	e Cut			R	ough Cut	Roug Fin	jh and iish	Lig Fini	ht and ish Cut	
Cast Iron-	Soft-(I	Under 20	0 Brinn	e [])			70	80.	.90	11	20	
Cast Iron-Med(200-300 Brinnell)							55	60.	70	120		
Cast Iron-Hard-(Over 200 Brinnell)							40	50-60		70		
Steel (Chrome Nickel 40-45 Shore)							30		40		50	
Steel (Stainless)							20		40		90	
Steel (Low Carbon)							80		90		140	
Steel (High Carbon)							40		50		70	
Bronze (Medium)							90	120		150		
Bronze (H	ard)	·					65	90		130		
Brass (He	ard)					1	00	15	0	200		
Copper						1	50	20	ů 0	20	0	
Duralumin	um						400		-	60	20 20	
Aluminum						6	500	***	•	100	0	
		т	ABLE	OF CUT	TING SE	PEEUS	AND FI	EEDS				
Es.et Per												
Mîri ute	15	20	25	30	40	50	60	70	80	90	100	
Dia meter, Inches				Rev	olutions	Per Mi	nute					
1/16"	917	1222	1528	1833	2445	3056	3667	4278	4889	5500	6112	
1/8	458	611	764	917	1222	1528	1833	2139	2445	2750	3056	
3/10	306	407	509	611	815	1019	1222	1426	1630	1833	2037	
5/1/1	229	306	382	458	611	764	917	1070	1375	1375	1528	
3/10	183	244	306	367	489	611	733	856	978	1100	1222	
J/0 7/1/17	100	204	255	306	407	509	611	713	815	917	1019	
1/10	131	175	218	262	349	437	524	611	698	786	873	
Į/∡ ⊊/0#	01	153	1 50	229	306	382	458	535	611	688	764	
2/411	71	122	103	183	244	306	367	428	489	550	611	
J/4 7/0#	/0	102	127	153	204	255	306	357	407	458	509	
1/0	67	8/	109	131	175	218	262	306	349	393	437	
1 1 /0**	57	/0	95	115	153	191	229	267	306	344	382	
11/0	20	6/	84	102	136	170	204	238	272	306	340	
1 1/4	43	01	/6	71	122	153	183	214	244	275	306	
13/0	41	22	69	83	111	139	167	194	222	250	278	
1 6 /01	38	50	63	76	102	127	153	178	204	229	255	
1 3/8	35	4/	58	70	94	118	141	165	188	212	235	
1 3/4	32	43	54	65	87	109	131	153	175	196	218	
2"	28	40 38	50 47	61 57	81 76	102	122	143 134	163	183 170	204	
·				57	70	75	115	104	133	1/2	141	

GENERAL SPEED RECOMMENDATIONS

PARTS IDENTIFICATION

Ê

1



BASIC MACHINE

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	2193500	Quill Housing ADT Coor	70	1111010	Machan
2	2060129	Pam Manter	70	1010796	Wasner Knog Binder Dlur (Dlastic)
4	1060892	Shan Ding	71	1011275	Niee Binder Plug (Plastic)
5	1011216	Shap King	72	1011375	Dog Point Set Screw
5	1062206	Vortigal Minsting Norm	73	1011270	Set Screw
7	2060125	Vertical Adjusting Worm	74	1011/55	Jam Nut
,	2060135	Worthighl Adjusting Warm Chaft	75	2060071	Key
0	2060130	Vertical Adjusting worm Shart	76	2060072	Washer
3	2060138	worm key	77	1062204	Bevel Gear
10	2060128	Ram	79	1060205	Sealed Ball Bearing
13	1011035	Socket Cap Screw (2 Req.)	80	2060070	Bearing Retainer Ring
14	1010590	Roll Dowel Pin	81	1011030	Socket Head Cap Screw
15	1062826	Angle Plate	82	2061238	Elevating Screw Assembly
10	1011555	Round HD Drive Screw (5 Req.)	83	2060060	Handle
17	2061028	Adapter Pivot Pin	84	2060080	Elevating Crank
18	2200109	Chamfered & Hardened Washer (7 Req.)	85	2060079	Gearshaft Clutch Insert
19	1061180	Adapter Locking Bolt (3 Req.)	86	2060078	Dial Lock Nut
23	2060021	Table 36" $(2060022 - 42" - 2060023 - 48")$	87	2060076	Dial with 100 Graduations
31	1061602	Stop Piece T-Bolt (3 Req.)	88	2060077	Dial Holder
32	1062301	Table Stop Piece (2 Req.)	89	1011030	Socket Head Cap Screw
33	1011720	Hex Nut (3 Req.)	90	2060210	Bearing Retaining Ring
37	2060120	Table Lock Bolt Handle	91	1060204	Grease Sealed Bearing
38	2060126	Saddle Lock Bolt	92	2060074	Bearing Cap
39	2060125	Saddle Lock Plunger	93	1013078	Кеу
40	1011071	Socket HD Cap Screw (2 Req.)	94	2060147	Elevating Shaft for 12" Knee
41	2060088	Gib Adjusting Screw (3 Req.)	95	1060204	Grease Sealed Bearing
42	2060121	Table Stop Bracket	96	1062205	Bevel Pinion
43	2060117	Saddle/Table Gib	97	1011220	Set Screw
44	1062406	Felt Wipers (4 Req.)	98	2060209	Column
46	2060118	Table Lock Plunger	102	1011074	Socket Head Cap Screw
47	2060119	Table Lock Bolt	103	2060207	Pedestal
48	2060120	Table Lock Bolt Handle	104	2060051	Elevating Screw Nut
49	2060124	Saddle/Knee Gib	105	1011033	Socket Head Cap Screw
50	2060123	Saddle Knee Wiper Plate (2 Req.)	118	2060144	Spider
51	1011580	Oval Head Screw (6 Req.)	119	2060133	Ram Lock Stud
52	2060097	Saddle	120	2060134	Ram Pinion
53	2060093	Left Hand Column Wiper Holder	121	2060139	Ram Pinion Handle
54	1062405	Knee Wiper Felt	122	1192150	Plastic Ball
55	2060146	Knee/Column Gib	123	2200109	Chamfered x Hardened Washer
56	1011035	Allen Cap Screw (2 Req.)	124	2060143	Turret
57	2060094	Right Hand Column Wiper Holder	125	2060137	Ram Clamp Bar
58	1062405	Knee Wiper Felt	126	2060141	Ram Clamp Untapped
60	1060152	Chip Guards - Upper	127	2060136	Ram Clamp Tapped
61	1060153	Chip Guards - Lower	128	1010770	Split Pin
62	2060206	Knee 12"	129	1061178	Locking Bolt
64	2060095	Stop Screw	130	2060140	Ram Pinion Screw
65	2061230	Knee Lock Shaft Assembly	131	1113051	Wrench
69	2060089	Knee Lock Plunger	132	2650180	Stop Bracket
			133	2069999	Stop Pin
				~~~~	



# LEADSCREW ASSEMBLY

(See pages 48 thru 50 for Metric Kits)

ITEM NO.	CODE NO.	DESCRIPTION				
1	1011755	Jam Nut (3 Req.)				
2	2060085	Ball Crank Handle (5 Key.)				
3	2060078	Dial Lock Nut (3 Req.)				
4	2060083	Dial with 200 Graduacions (5 Meq.)				
5	2060084	Dial Holder (3 Req.)				
6	1011030	Socket Cap Screw (6 Reg.)				
7	2060075	Bearing Retainer Ring (2 Req.)				
8	1060203	Grease Sealed Ball Bearings (2 Req.)				
10	1011074	Socket Cap Screw (12 Req.)				
11	2060116	Right Bearing Bracket				
12	2060115	Left Bearing Bracket				
13	1060204	Grease Seal Ball Bearing				
14	1013078	No. 7 Woodruff Key (3 Req.)				
15	2061222	Longitudinal Feed Screw 42" (48" also				
		available 2061223)				
16	1011592	Washer Head Screw (2 Req.)				
17	2060100	Cross Feed Nut Retaining Screw (2 Req.)				
18	2060102	Longitudinal Feed Nut				
20	2060099	Key (2 Req.)				
21	1011074	Socket Cap Screw (4 Req.)				
22	2061250	Feed Nut Bracket				
23	2060096	Key Pin				
24	2060098	Cross Feed Nut				
26	2190188	Stop Pin				
27	2061233	Cross Feed Screw for 12" Knee				
28	2060082	Cross Feed Bearing Bracket				



# J HEAD TOP HOUSING

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	2193502	Drawbar for R.8 Collet	42	2193507	Belt Housing
2	2190183	Drawbar Washer	43	2193541	Motor Locknut (2 Req.)
3	2190126	Upper Bearing Locknut	45	2190172	Motor Locknut Handle (2 Req.)
4	2190125	Bearing Sleeve Locknut	46	1192151	Black Plastic Ball (2 Req.)
5	1190232	Ball Bearing	49	2193508	Motor Pulley
6	2193506	Upper Bearing Spacer (small)	50	2193452	Gear Housing Cover
7	2193506	Upper Bearing Spacer (large)	51	1011455	Round HD Screw (5 Req.)
8	1190232	Ball Bearing	52	1195720	Wick
9	1192032	Compression Spring (4 Req.)	53	2190120	Oiler Tube
10	1011258	Socket Set Screw (2 Req.)	54	2190121	Oiler Plug
11	2193512	Spindle Pulley Bearing Sleeve	55	1193105	Oil Cup
12	1011743	Jam Nut	56	2190116	Bull Gear Key
13	1191965	External Lock Washer	57	2190115	Splined Gear Hub
14	2193516	Brake Ring Screw (3 Req.)	58	2193548	Spindle Bull Gear Assembly
15	1192084	Spring (2 Req.)	59	1180235	Bearing
16	1010507	Roll Pin (4 Req.)	60	2190136	Countershaft
17	2190131	Brake Lock Stud	61	1013079	Кеу
18	2193477	Brake Assembly	62	2190137	Countershaft Gear
19	2190055	Spindle Pulley	63	1180235	Bearing
20	2193478	Spindle Pulley Hub	64	1010747	Dowel Pin
22	1192101	'V' Belt	65	2190062	Back Gear Shifter Fork
23	1182106	Timing Belt	66	2193505	Gear Housing
24	2190058	Timing Belt Pulley Flange	67	1010540	Dowel Pin (2 Req.)
25	2193509	Timing Belt Pulley	68	1010555	Roll Pins (2 Req.)
26	2190058	Timing Belt Pulley Flange	69	1011104	Socket Cap Screw (6 Req.)
27	1011506	Flat Head Screw	71	1190230	Ball Bearing
28	1191738	Hex Jam Nut	72	1190806	Snap Ring
29	1192151	Black Plastic Ball Handle (2 Req.)	73	1191944	Lockwasher
30	2190128	Spindle Clutch Lever	74	1191793	Bearing Locknut
31	2190127	Cam Ring	75	1011718	Hex Nut Hardened (3 Req.)
32	2190129	Cam Ring Pin (2 Req.)	76	2193515	Vertical Tee Bolt (3 Req.)
33	1011215	Socket Set Screw	77	2190114	Vertical Bolt Washer (3 Req.)
34	2190133	Brake Lock Handle	78	2193545	Back Gear Shift Crank
35	2190134	Brake Lock Pin	79	1010517	Roll Pin
36	2190132	Brake Lock Washer	80	2190186	Back Gear Shift Bushing
37	1192830	Spindle Speed Plate	81	2193443	Shift Crank
38	1192832	Operating Instruction Plate	82	1192151	Black Plastic Ball 1" Dia.
39	1191796	Hex Jam Nut (2 Req.)	83	2190138	Gearshift Plunger
40	1191922	Lock Washer	84	1192052	Compression Spring
41	2190173	Motor Mounting Studs (2 Req.)	85	2190040	Belt Guard Assembly



# Ј НЕАД (See page 48 for Metric Kit)

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	1011445	RD. HD. Screw	59	2190201	Pin
2	2190163	Bevel Pinion Washer	60	2190179	Feed Shift Rod
3	2190203	Feed Bevel Pinion	61	1011260	KP. Set Screw
4	2190164	Feed Worm Gear Shaft Sleeve	62	2190162	Кеу
5	1192303	Worm Cradle Bushing	63	2190061	Feed Gear Shift Fork
6	1011287	Setscrew	64	2193446	Cluster Gear Shift Crank
7	2190165	Worm Gear Spacer (4 Reg.)	65	1011270	Socket Set Screw
8	2190166	Feed Drive Worm Gear	66	2190065	Cluster Gear Cover
9	2190167	Feed Drive Worm Gear Shaft	67	1011010	Cap Screw (4 Reg.)
10	2190162	Worm Shaft Key	68	2190138	Gear Shift Plunger
11	1013078	Key	69	1192052	Compression Spring
12	1011771	Locknut	70	2193443	Shift Crank
13	2190199	Washer	71	1010517	Roll Pin
14	2190176	Cluster Gear Key	72	1192151	Black Plastic Ball
15	1192209	Feed Reverse Bevel Gear	73	1011014	Cap Screw (2 Reg.)
16	2190168	Feed Engage Pin	74	2190188	Clutch Ring Pin (2 Reg )
17	2190059	Worm Gear Cradle	75	2190098	Clutch Ring
18	2190169	Worm Gear Cradle Throw-out	76	1011265	Socket Set Screw
19	2190170	Shift Sleeve	70	2200110	Brace Dive
20	2190138	Gearshift Plunger	78	2190105	Overload Clutch Lockput
21	1192052	Compression Spring	78	1192055	Safety Clutch Spring
22	1010517	Roll Pin	20	11022033	Granland Clutch
23	2193443	Shift Crank	01	2102540	Overload Clutch Sloave
24	1192151	Black Plastic Ball	01	1101020	Cingle Cruice Magher (2 Deg.)
25	1011010	Can Screw (3 Reg.)	82	1011423	Single Spring Washer (3 Req.)
25	1011258	Set Screw	83	1011431	Round Head Screw (3 Req.)
20	2190191	Cluster Gear Shaft Upper Bearing	84	1011542	Mock-it Lockscrew
28	2193504	Cluster Gears Assembly	85	1011268	Socket Set Screw
20	2190175	Cluster Gears Assembly	86	1011542	LOCKSCIEW
29	21901/9	Pound End Kow	87	1011268	Socket Set Screw
21	2190148	Cluster Coar Shaft	88	1192032	Compression Spring
32	1100026	Cluster Gear Shart	89	2190096	Overload Clutch Lever Spring Plunger
32	1190836	Shap King	90	2190106	Quill Pinion Shaft Bushing
33	2190149	Devel Gear Manuch Concern	91	2190104	Pinion Shaft Worm Gear Spacer
34	2190150	Bever Gear Influst Spacer	92	2190103	Overload Clutch Worm Gear
35	2193544	Feed Reverse Bever Finion	93	2190102	Overload Clutch Ring
30	2190146	reed briving Gear	94	1190870	Snap Ring
37	2190176	Rey Cluster Coor Innut Chaft	95	1010717	Dowel Pin
38	2193440	Cluster Gear Input Shart	96	2193427	Overload Clutch Trip Lever
40	2193440	Feed Drive Gear	97	2190097	Overload Clutch Washer
41	1190310	Needle Bearing	98	1190822	Snap Ring
42	1193637	Busning	99	2190068	Clutch Arm Cover
43	1192208	worm	100	1011308	Socket Set Screw
44	2190155	reed worm Shart Bushing	101	1011740	Chem Blacked Locknut
45	1011268	Socket Set Screw	103	2190094	Cam Rod
46	1011542	Mock-1t Lockscrew	104	2190095	Trip Handle
47	2190152	Feed Worm Shaft Thrust Washer	105	1192151	Black Plastic Ball
48	1193635	Bushing	106	2190067	Feed Trip Bracket
49	2193432	Feed Reverse Bevel Gear	107	1011035	Cap Screw (2 Req.)
50	2190153	Feed Reverse Clutch	108	1011222	Socket Set Screw
51	2193432	Feed Reverse Bevel Gear	109	2190162	Кеу
52	1193635	Bushing	110	2193547	Feed Reverse Knob Stud
53	1011547	Socket Set Screw	111	2193433	Reverse Knob
54	1011375	Socket Set Screw	112	1180818	Snap Ring
55	2190157	Reverse Clutch Rod	113	2193518	Handwheel Clutch
50	1010203	KOII PIN	114	1192165	Steel Ball
57	5190198	reed worm Shaft	***		Accet barr
58	2190200	PIN			



# JHEAD (CONTINUED) (See page 48 for Metric Kit)

ITEM NO.	CODE NO.	DESCRIPTION				
115	1192054	Compression Spring				
116	2190154	Handwheel Clutch Spring Screw				
117	1010515	Roll Pin				
118	2190093	Cam Rod Sleeve Assy.				
119	1010513	Roll Pin				
120	1192053	Compression Spring				
121	2193456	Trip Plunger				
122	2190092	Feed Trip Plunger Bushing				
123	2190090	Trip Plunger Bushing				
124	2190089	Feed Trip Plunger				
125	2193503	Handwheel				
127	2193511	Spindle				
128	2190081	Quill Skirt				
129	1191790	Locknut				
130	1191942	Lockwasher				
131	1190237	Bearing				
132	2190197	Sleeve				
133	2190196	Nose-piece				
134	2190193	Spindle Dirt Shield				
135	1190239	Bearing				
136	2193513	(Bearing Spacer - Large				
137		(Bearing Spacer - Small				
138	1190239	Bearing				
140	1011545	Special Socket Set Screw				
141	2193540	Collet Alignment Screw				
142	2190192	Quill (O.D. Within .0001")				
144	1011303	Socket Set Screw				
145	2193498	Feed Trip Lever				
146	2190185	Trip Lever Pin				
148	2190110	Quill Lock Sleeve				
149	2200098	Lock Handle				
151	1192403	Felt Washer				
152	2190111	Quick Lock Bolt				
153	2190109	Quill Lock Sleeve Tapped				
155	2193546	T-Bolt Assy.				
156	2190135	Lower Clamping Bolt Spacer (2 Req.)				
157	1191736	Locknut				
158	1011411	Chem Blacked RD.HD. Screws (2 Req.)				
159	1195306	Micrometer Scale				
160	1190836	Snap Ring				
161	2190190	Quill Micro-stop Nut				
162	2190084	Micrometer Nut				
163	2190082	Quill Stop Knob				
164	2190083	Quill Stop Micro-screw				
165	1011090	Screw				
166	2193501	Quili Pinion Shaft				
167	1013078	Key				
168	2200111	Spring Pin				
169	1011445	RD. Head Screw (2 Req.)				

ITEM NO.	CODE NO.	DESCRIPTION
170	1010717	Roll Pin
171	1013076	Кеу
172	2190182	Pinion Shaft Hub Screw
173	1192165	Steel Ball
174	1192033	Compression Spring
175	2201031	Rack Feed Handle Hub
176	2190079	Pinion Shaft Hub Sleeve
177	2193436	Spring Cover
178	1192020	Clock Spring (Clock Spring Assy. 2193437)
179	2190184	Outside Spring Pin
180	2190108	Quill Pinion
181	1011268	Socket Set Screw
182	1011542	Lockscrew
183	2190085	Reverse Trip Ball Lever
184	2190086	Feed Reverse Trip Plunger
185	2190087	Reverse Trip Ball Lever Screw
186	1192207	Worm Gear
187	1013077	Кеу
188	1011370	Socket Set Screw
189	2190177	ADJ Worm Shaft
190	2201032	Pinion Shaft Hub Handle
191	1202170	Black Plastic Ball Handles
192	2193514	Quill Housing



)j

# 2J HEAD TOP HOUSING

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	1011743	Hex Cap Nut	49	2180054	Fixed Clutch Bracket
2	1180033	Vari-Speed Dial	50	1011246	Socket Set Screw
3	1183646	Bronze Bearing	51	2180105	Guide for Clutch Bracket
4	1011380	Full Dog Socket Set Screw	52	1011016	Flat HD Socket Cap Screw (2 Req.)
5	2180055	Speed Changer Housing	53	1010511	Dowel Pin
6	1185325	Speed Changer Chip Shield	54	1183104	Oil Cup
7	1011420	Machine Screws (2 Req.)	55	1182071	Compression Spring (3 Req.)
8	1183655	Bearing	56	1181794	Bearing Locknut
9	1010520	Roll Pin	57	2180061	Bearing Sleeve
9a	1010534	Roll Pin	58	1181977	Wave Spring Washer
9Ъ	2180066	Speed Change Stud	59	2180067	Bull Gear Shift Pinion
10	1183720	Speed Changer Chain	60	2180097	HI-LOW Detent Plate
11	1182655	Drum Switch	61	1181732	Hex Nut (3 Req.)
12	2183923	Belt Housing Assembly	62	1181910	Lock Washer (3 Rèq.)
13	2180094	Top Bearing Cap	63	2180085	Studs (3 Req.)
14	1011065	Soc HD Cap Screw (2 Req.)	64	1011284	Socket Set Screw
15	2190201	Roll Pin	65	2180098	Adjustable Plate
16	1181923	Spring	66	2180100	HI-LOW Detent Plunger
17	1180214	Bearing	67	1182072	Spring
18	2182002	Speed Change Shaft	68	1011017	Socket Cap Screw (2 Req.)
19	1182178	Handle	69	1192151	Bakelite Ball Handle
20	1182892	Caution Plate	70	2180099	HI-LOW Shift Crank
21	2182001	Speed Change Handwheel	71	2180096	HI-LOW Pinion Block
22	1011133	Flat Hd. Cap Screw (2 Req.)	72	1010516	Roll Pin (2 Req.)
23	1182901	Plastic Face Plate	73	1011052	Socket Cap Screw (4 Req.)
24	1181233	Set Screw	75	1011012	Socket HD Cap Screw
25	1011037	Socket HD Cap Screw (4 Req.)	76	2180088	Motor Pulley Cover
26	1011287	Socket Set Screw	77	1011287	Socket Set Screw
27	1183645	Bronze Bearing	78	1013079	Key (2 Req.)
28	2190201	Pin	79	1180235	Ball Bearing (2 Req.)
29	2180087	Speed Control Shaft	80	2180075	Bull Gear Pinion Counter Shaft
30	1192208	Worm Gear	81	2180103	Кеу
31	1183636	Bearing	82	1181975	Wave Spring Washer
33	2180090	Speed Changer Spur Gear	83	2183933	Bull Gear Pinion
35	2180065	Speed Change Chain Drum	84	2180076	Bull Gear Pinion Bearing Cap
36	1182106	Belt	85	1011011	Socket HD Cap Screw (2 Req.)
37	2180060	Spindle Pulley Hub	86	2550016	Timing Belt Pulley
38	2180064	Timing Pulley Clutch Sleeve	87	1191738	Jam Nut
39	2180059	Splined Gear Hub	FOR	2 HP HEAD.	SUBSTITUTE THE FOLLOWING:
40	2183933	Spindle Bull Gear Assembly	1010		
41	1180254	Ball Bearing (2 Req.)	36	1552106	Belt
42	2180092	Snap Ring (2 Reg.)	37	2550012	Pulley Hub
43	2180063	Bull Gear Bearing Spacer	38	2550013	Clutch Sleeve
44	2180053	Gear Housing	86	2180091	Pulley
45	1181620	vert. Tee Bolts (3 Req.)			
46	1181906	Steel washer (3 Req.)			
47	1011750	Hex Jam Nut - Finished HDN. (3 Req.)			
48	1181986	Ball Bearing Gear Sleeve Washer			

.



# 2J HEAD ASSEMBLY (SEE PAGE 48 FOR METRIC KIT)

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	1011033	Socket Cap Screw (3 Reg.)	42	1182123	Plastic Insert (2 Reg.)
2	2180094	Top Bearing Cap	43	2183931	Adjustable Motor Varidisc Assembly
3	1181977	Spring Washer	44	1182083	Spring for Varidisc Motor Shaft
4	1180252	Ball Bearing	45	1182305	Adjustable Varidisc Spring Collar
5	1180848	Snap Ring No.	46	1011065	Socket HD Cap Screw (2 Reg.)
6	1011069	Socket HD Cap Screw (2 Req.)	47	1180860	Ret. Ring
7	1011745	Hex Jam Nut	48	1011052	Socket Cap Screw
8	2015171	Motor 1 1/2 HP (complete unit) 230/460 3/60	49	1182122	Plastic Key
8a	1550001	2 HP Motor	51	2180084	Key
8b	2550019	2 HP Motor Assembly	52	2180107	Taper Pin
9	1011148	Hex HD Screw (2 Req.)	53	2183923	Belt Housing Base
10	2183923	Belt Housing	54	2180088	Motor Pulley Cover
11	2180066	Speed Change Chain Stud	55	1011012	Socket Cap Screw
12	1010534	Roll Pin	56	1011552	Drive Screw (4 Req.)
13	2180058	Speed Change Plate	58	1182893	HI-LOW Range Nameplate
14	2183920	Drawbar	59	1011552	Drive Screw (4 Req.)
15	1010604	Cotter Pin	60	2180107	Taper Pin (2 Reg.)
16	2180074	Speed Change Plate Pivot Stud	61	1182894	Quill Feed Nameplate
17	1011125	Socket HD Cap Screw (2 Req.)	62	1011552	Rivets (4 Req.)
18	2180095	Washer	63	2180053	Gear Housing
19	2180089	Pivot Sleeve (2 Req.)	64	1011443	Round HD. Machine Screw (3 Req.)
20	2180093	Draw Bar Washer	65	1185030	Gear Housing Plate
21	1180915	"O" Ring	66	1180818	Snap Ring
22	2180056	Spindle Pulley Bearing Sliding Housing	67	2180083	Brake Finger Pivot Stud
23	1180253	Ball Bearing	68	2180072	Brake Operating Finger
24	1182124	Plastic Insert (2 Req.)	69	1192151	Bakelite Ball Handle
25	2183934	Adjustable - Driven Varidisc	70	2190133	Brake Lock Handle
26	1180855	Snap Ring No.	71	2190134	Brake Lock Pin
27	1182120	Belt	72	1011215	Socket Set Screw
28	2180082	Stationary Driven Varidisc	73	2180104	Sleeve for Brake Lock Shaft
29	2180057	Brake Bearing Cap	74	2180070	Brake Lock Shaft
30	1180253	Ball Bearing	75	2180069	Brake Lock Cam
31	1182081	Brake Spring (2 Req.)	76	1010534	Roll Pin
32	2180073	Brake Shoe Assembly (2 Req.)	7 <b>7</b>	1011287	Socket Set Screw
33	2180078	Spindle Pulley Spacer	FOR		SUBSTITUTE THE FOLLOWING.
34	2180060	Spindle Pulley Hub	POR	z ne neko,	SUBSTITUTE THE FOLLOWING:
35	1011140	Hex HD. Screw	38	2550007	Key
36	2180071	Brake Shoe Pivot Sleeve	39	2550004	Key
37	1010501	Roll Dowel Pin	40	2550006	Stationary Varidisc
38	2180102	Drive Key	42	1182126	Plastic Insert (2 Req)
39	1182121	Key for ADJ Varidisc Motor Shaft	43	2550005	Adjustable Varidisc Assembly
40	2180080	Stationary Motor Varidisc	43A	2550023	Adjustable Varidisc Assembly
41	1011287	Socket Set Screw	44	1182083	Spring
			45	2550003	Spring Collar
			47	1170865	Ret. Ring



# M HEAD (See page 48 for Metric Kit)

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	2204826	Spindle Pulley Hub Simple Date a			
2	2200069	Spindle Pulley Single Belt Drive	57	1011116	Cap Screw
3	2200072	Bearing Retainer Ding	58	1202845	Micrometer Scale
4	1200202	Ball Bearings (2 Pog.)	59	1011411	Flat Head Screw (2 Reg )
5	2204834	Bearing Housing	60	2190084	Micrometer Nut
6	1241940	Bearing Lock Washer	61	1011720	Hex Nut (4 Reg.)
7	1241786	Bearing Lock Nut	62	2200076	Micrometer Lock Nut
8	1202450	Paper Gasket	63	2200100	Quill Lock Sleeve, Drilled
9	1011040	Cap Screw (6 Peg )	64	2200099	Quill Lock Bolt
10	1202102	V Belt	65	2200098	Quill Lock Bolt Handle
11	2204847	Motor Pulley Single Deine	66	2200077	Micrometer Screw
13	1011240	Set Screw	67	2200110	Brass Plug
14	1011715	Hex Nut (2 Peg )	68	1011265	Set Screw
15	2200109	Chamfered & Hardoned Western	69	2200101	Quill Lock Sleeve, Tarmed
16	1011855	Motor Mounting Ping Shud (2 a	70	2204832	Quill Housing
17	1203108	Oil Cup	73	1201788	Bearing Lock Nut
18	2204833	Belt Housing Simila Dala Dala Da	74	1191942	Bearing Lock Washer
19	2204854	Belt Guard Assembly	75	1200201	Ball Bearing (A Reg.)
26	1011236	Set Screw	76	2204840	Outside Bearing Spacer)
27	1011170	Her Head Screw	77		Inside Bearing Spacer ) Machined as unit
28	2200109	Chamfered & Randon d Harl	78	1200201	Ball Bearing (A Beg )
29	2200106	Brass Ouill Skint	79	2200064	Long Spacer aligner spring sturest
33	1011455	Round Head Server (2 Dr. )	80	2200053	Ouill
34	2200093	Ouill Feed Clutch Kach	81	1011265	Set Screw
35	2200092	Spring Comm	82	1200201	Ball Bearing (4 Reg.)
36	2200108	Outside Spring Di-	83	2204842	Outside Bearing Spacer
37	1202021	Clock Spring	84		Inside Bearing Spacer ) Machined as unit
38	2200111	Pinion Spring Die	85	1200201	Ball Bearing (4 Reg.)
39	2200091	Split Bushing	86	2200060	Nosepiece
40	2204837	Ouill Food Divisor	87	2200097	Ouill Feed Worm
41	1013076	Pinion Key	88	1633638	Bronze Bearing
42	1202452	Fibre Wachen (2 Bar )	89	2200107	Straight Pin
43	2200090	Quill Feed Norm Wheel	90	2200112	Straight Pin
44	2204836	Quill Feed Clubek Wel	91	2200096	Ouill Feed Worm Wub
45	1010541	Poll Pin	94	2204849	Ouill Worm Feed Wardsheet as
46	2201031				guard worm reed handwheel Assembly
49	1011265	Set Sarow			
50	2204835	Drawbar Knob			
51A	2204845	Drawbar Single Drive #2 m . rs -			
51B	2204846	Drawbar, Single Drive #2 MT & #/ B & S Taper			
52	1202170	Ball			
53	2203466	Rack Feed Handle			
54	2201032	Drawbar Nut			
55A	2204820	Spindle, Single Bolt #2 wm man			
55B	2204821	Spindle, Single Polt #7 D c c man			
55C	2204822	Spindle, Single Bolt D-2 manual			
56	2200073	Micrometer Stop			



# SHAPING ATTACHMENI

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	2240061	Belt Cover	56	1243180	Oilsen
2	1242104	Belt	57	2240082	Key
3	2240814	Worm Shaft Pulley	58	2240085	Key
4	2240087	Кеу	59	2240063	Crank & Shaft
5	1011240	Set Screw	60	2240064	Cranknin Block
6	1011239	Set Screw	61	2240074	Posting Detaining Machan
7	2240811	Motor Pulley	62	1011502	Bound Wood Canna
8	2240086	Pin (2 Req.)	63	2240070	Cranknin Block Hold-Down
9	1011530	Flat Screw (4 Reg.)	64	1011515	Flat Moad Saray (10 Dec.)
10	2240059	Belt Housing	65	1011427	Pound Wood Carry (2 Dec.)
11	2240090	Belt Cover Clip	66	2240069	Round nead Screw (3 Red.)
12	1011590	Washer Head Screw	67	2240080	Rack Dinion Coort & Chaft
13	1011850	Motor Mounting Ring Stud (2 Reg.)	68	2240080	Finiton Gear & Shart
14	2060122	Washer	69	2240083	Rey
15	1011720	Hex Head Nut	70	12/2101	
16	1011061	Cap Screw (3 Reg.)	70	1243101	Dilseal Repairs
17	2240079	Air Vent Cover	71	1240210	Ball Bearing
18	1011592	Washer Head Screw (2 Reg.)	72	2240214	Ball Bearing
20	2240810	Ram Housing	73	2240071	Worm Gear
21	1243107	Oil Cup	75	1011030	Gear Housing Cover
22	1242808	Nameplate	75	1241040	Cap Screw (3 Req.)
23	1011552	Drive Screws	70	1241740	Lockwasner
24	1011265	Set Screw	77	2240060	Lockhut
25	2240150	Brass Plug	70	2240000	Crank Bearing Cover
26	1242402	Felt Plug	/3	1011033	Cap Screw (3 Req.)
27	2240056	Ram Cover	80	2240066	Stroke Adjustment Plate
28	1011030	Cap Screw	81	1242050	Dial Spring
29	1240303	Inner Race	82	2240055	Stroke Adjustment Dial
30	1240302	Bearing	83	2240088	wasner
31	2240057	Gib	64	2240089	Acorn Nut
32	1240305	Inner Race	93	1011270	Set Screw
33	1240304	Bearing	94	2240077	Clapper Box Clamp Shoe (2 Req.)
34	2240067	Connecting Rod	93	1011214	Set Screw
35	1011450	Ram Crankpin Lockscrew	96	2240813	Clapper Box
36	2240072	Ram Crankpin	97	1010748	Pin
37	2060088	Gib Screw	98	2240062	Clapper Spring
38	2240065	Bam	99	1011427	Round Head Screw
39	1242404	Wiper Felt	100	1011239	Set Screw
40	2240078	Wiper Plate	101	2240076	Clapper
41	1011407	Round Head Screw (4 Reg.)	102	1011214	Set Screw
42	1011009	Cap Screw (3 Reg.)	103	1011237	Set Screw
43	1243182	Oilseal			AVAILABLE TOOLING
44	2240073	Worm Bearing Cover		1045050	
45	1241784	Locknut		1245250	#1 Shaping Tool
46	1241932	Lockwasher		1245251	#2 Shaping Tool
47	1240217	Ball Bearing		1245252	#3 Shaping Tool
48	2240058	Worm & Shaft		1245253	#4 Snaping Tool
49	1240306	Bearing		1245254	#5 Snaping Tool
50	1242805	Rotation Nameplate		1245255	#6 Shaping Tool
51	1011552	Drive Screw		1245256	#/ Snaping Tool
52	2240091	Vent Plug		2240128	High Speed Cutters
54	2240051	Gear Housing		2240129	Tools with cutting edge unground
55	1010782	Pipe Plug		2240094	Complete Shaping Tools
				1243440	TOOL BIC. 3/16" Sq. x 2" for Shaper



-

# 6F LONGITUDINAL POWER FEED ASSEMBLY

ITEM NO.	CODE NO.	DESCRIPTION	ITEM NO.	CODE NO.	DESCRIPTION
1	2430097	Stop Rod Clamp	50	1632074	Clutch Spring
2	2060300	Bracket	51	1011074	Socket Hd Cap Screw
3	1632304	Stop Collar	52	1635040	Taper Plug
4	1010507	Roll Dowel	53	1010543	Dowel Pin
5	1011265	Socket Set Screw	54	1633638	Bronze Bushing
6A	2631054	Stop Rod - 42" Table	55	2630051	Main Housing
6B	2631055	Stop Rod - 48" Table	56	1013078	Woodruff Key (4 Reg.)
7	2630065	Control Lever	57A	2630084	Longitudinal Lead Screw - 42"
8	1632152	Ball	57B	2630085	Longitudinal Lead Screw - 48"
9	2270093	Stop Rod Clamp - Optics	58	1632073	Spring
10	2270088	Bracket - Optics	59	2630068	Detent Pin
11	1010516	Roll Dowel	60	2630075	Din
12	2430101	Fork Pin	61	1633650	Bronze Bearing
13	2630071	Stop Rod Fork	62	1010411	Taper Din
14	1630890	Retaining Ring	63	2630053	Side Cover
15	2630065	Control Lever	64	1622112	Oil Sight
16	1011277	Set Screw	65	1033112	10 - 24 = 5/9 Contract Con Course
17	2630072	Clutch Detent Cam	66	2630060	10 - 24 x 578 Socket Cap Screw
18	1010516	Roll Pin	67	2030000	Coupling Threat Marker
19	2630054	Control Lever Shaft	67	2030091	Infust washer
20	1632005	Clutch Arm Spring	. 68	2620060	Socket Ha Screw
21	1011740	Locknut	69	2630069	Gear Mounting Hub
22	1631925	Lockwasher	70	1632216	Gear (Spiroid)
23	2630076	Clutch Arm Spring Pin	70A	1032218	Gear (Spiroid) (Hi Torque)
24	2630074	Detent Boller	71	1011016	Socket Hd Cap Screw
25	2630087	Boller Pin	72	2630062	Clutch - Driving
25	1011705	Hey Nut	73	2630070	Thrust Bearing
20	1631925	Lockwasher	74	1630838	Retaining Ring
27	2620072	Clutch Arm	75	2630063	Clutch - Driven
29	1630320	Popring	76	2630092	Drive Shaft
30	1011576	Shouldon Saraw	77	2630066	Spacer
22	2621051	Motor Accombly	78	1011447	Pan Hd Machine Screw
327	2636423	Motor Assembly (Hi Morgue)	79	1011701	Hex Nut (4 Req.)
320	2030423	Rocor Assembly (HI Torque)	80	1632658	Limit Switch
33	1011033	Socket Cap Screw (4 Red.)	81	1011404	Rd Head Machine Screw
34	2630094	Roll Pin	82	2630058	Switch Actuator Housing
35	1632006	Spring	83	2630059	Switch Actuator Pin
36	1633728	Motor Cap	84	1632610	Switch Mounting Plate
37	2630081	Handle Assembly	85	2630052	Control Box
38	1011755	Jam Nut	86	1011046	Socket Hd Cap Screw (2 Reg.)
39	2200109	Washer	87	1632576	Power Feed Control Plate
41	1633653	Bushing	88	1011190	Button Hd Socket Screw (4 Reg.)
42	2060078	Dial Locknut	89	1632659	Switch
43A	2060083	Dial - Inch	90	1632607	Fuse Socket
43B	2069016	Dial - Metric	91	1632606	Fuse
44	2630064	Dial Holder	92	1632593	Pilot Light
45	1011011	Socket Hd Screw	93	1632153	Knob
46	2630089	Take-up Cap	94	1632618	Potentiometer
47	2630067	Lead Screw Seal	95	1632620	Pushbutton Switch
48	1630261	Bearing	96	1632628	Boot
49	1630814	Retaining Ring	97	1632568	PC Board
			98	1010545	Roll Pin



Figure 11. Circuit Diagram - Motors





#### METRIC CONVERSION KITS

The following metric conversion kits are available:

CODE NO. 2204000 - "M" HEAD, METRIC CONVERSION KIT

Consisting Of:

1202846 - Scale 2209002 - Stop Screw 2199002 - Micro Nut 2199005 - Stop Nut

#### CODE NO. 2184000 - "J" & "2J" HEAD, METRIC CONVERSION KIT

#### Consisting Of:

1195307 -	Scale
2199001 -	Stop Screw
2199002 -	Micro Nut
2199005 -	Stop Nut

## CODE NO. 2064001 - METRIC CONVERSION KITS FOR HANDFEED MACHINES WITH 36" TABLES.

Consisting Of:

- 2060175 Table Leadscrew
- 2060183 Elevating Leadscrew
- 2060172 Table Feed Nut
- 2060171 Saddle Feed Nut
- 2060170 Elevating Nut
- 2069016 Table & Saddle Dial (3)
- 2069015 Elevating Screw Dial (1)
- 2060182 Saddle Leadscrew

# CODE NO. 2064002 - METRIC CONVERSION KITS FOR HANDFEED MACHINES WITH 42" TABLES.

# Consisting Of:

1

2060177 -	Table Leadscrew
2060183 -	Elevating Screw
2060172 -	Table Feed Nut
2060171 -	Saddle Feed Nut
2060170 -	Elevating Nut
2069016 -	Table & Saddle Dial (3)
2069015 -	Elevating Screw Dial (1)
2060182 -	12" Saddle Feed Screw

# CODE NO. 2064003 - METRIC CONVERSION KIT FOR HANDFEED MACHINES WITH 48" TABLES.

# Consisting Of:

2060179 -	Leadscrew	
2060183 -	Elevating Screw	
2060172 -	Table Feed Nut	
2060171 -	Saddle Feed Nut	
2060170 -	Elevating Nut	
2069016 -	Table & Saddle Dial	(3)
2069015 -	Elevating Screw Dial	(1)
2060182	1911 Saddle Food Scree	137

# CODE NO. 2064004 - METRIC CONVERSION KIT 36" TABLE W/POWER FEED

#### **Consisting Of:**

2630096 -	36" Table Leadscrew	
2060183 -	Metric Elevating Screw	
2060172 -	Metric Table Feed Nut	
2060171 -	Metric Saddle Feed Nut	
2060170 -	Metric Elevating Nut	
2069016 -	Metric Table & Saddle Dial	(3)
2069015 -	Metric Elevating Screw Dial	(1)
2060182 -	Metric 12" Saddle Feed Dial	

## CODE NO. 2064005 - METRIC CONVERSION KIT 42" TABLE W/POWER FEED

#### Consisting Of:

2630097 -	42" Table Leadscrew
2060183 -	Metric Elevating Screw
2060172 -	Metric Table Feed Nut
2060171 -	Metric Saddle Feed Nut
2060170 -	Metric Elevating Nut
2069016 -	Metric Table & Saddle Dial (3)
2069015 -	Metric Elevating Screw Dial (1)
2060182 -	Metric 12" Saddle Feed Screw

## CODE NO. 2064006 - METRIC CONVERSION KIT 48" TABLE W/POWER FEED

#### Consisting Of:

- 2630098 48" Table Leadscrew
- 2060183 Metric Elevating Screw
- 2060172 Metric Table Feed Nut
- 2060171 Metric Saddle Feed Nut
- 2060170 Metric Elevating Nut
- 2069016 Metric Table & Saddle Dial (3)
- 2069015 Metric Elevating Screw Dial (1)
- 2060182 Metric 12" Saddle Feed Screw

#### SPARE PARTS KITS

# CODE NO. 2062000 - SERIES I STANDARD MACHINES SPARE PARTS KIT

#### Consisting Of:

- 1062405 Way Wiper, Knee/Column (2)
- 1062406 Way Wiper, Knee/Column (4)
- 2060098 Leadscrew Nut Cross Feed (1)
- 2060102 Leadscrew Nut Long. Feed (1)

CODE NO. 2203000 - "M" MILLING HEAD - SPARE PARTS KIT

Consisting Of:

1202102 -	Drive Belt	
1202021 -	Clockspring	
1200202 -	Spindle Bearings	(4)
1191942 -	Lockwasher (2)	

# CODE NO. 2193000 - "J" MILLING HEAD - SPARE PARTS KIT

Consisting Of:

1182120 -	Drive Belt (1)
1182106 -	Timing Belt (1)
2193477 -	Brake Shoes (2)
1192084 -	Brake Springs (2)
2193437 🔺	Clocksprings Assy. (1)
2180117 -	Gear Lube (1)
1190239 -	Spindle Bearings (Pair)
1190237 -	Spindle Bearing (1)
1192403 -	Felt Wipers (2)
1191942 -	Lockwashers (2)
1011392 -	Collet Aligning Screws (6)

# CODE NO. 2183000 - "2J" MILLING HEAD (1 1/2 H.P.) - SPARE PARTS KIT

**Consisting Of:** 

1182120 -	Drive Belt (1)
1182106 -	Timing Belt (1)
2180073 -	Brake Shoes (Set)
1182081 -	Brake Springs (1)
1182121 -	Key, Motor (1)
1182122 -	Key, Driven (1)
2193437 -	Clockspring Assembly (1)
2180117 -	Gear Lubricant (1)
1183147 -	Lubriplate (1)
1190240 -	Spindle Bearings (Pair)
1190237 -	Spindle Bearing (1)
1192403 -	Wiper, Felt (2)
1191942 -	Lockwasher (2)
2193540 -	Collet Alignment Screw (6)

# CODE NO. 2553000 - "2J" MILLING HEAD (2 H.P.) - SPARE PARTS KIT

Same as above except:

1552106 - Timing Belt 1552121 - Key, Motor 1552122 - Key, Driven

#### These are tricks or tips I use when working on a Mill

These are intended for informational purposes only and not responsible for any injury or damage to the machine

#### Removal of motor on a variable speed head

Turn the spindle on and crank the RPM's down to the lowest RPM Shut off the spindle **disconnect the power to the machine** Remove the drum switch from the left side of the machine Underneath the motor is a half moon shaped cover. Take out the three 10-32 screws that hold the cover on. Looking up in the opening you will see a collar with a spring above Using two of the 10-32 screws stick them through the two holes in the collar and thread them into the varipulley. This secures the compressed spring. (If you cannot thread them this means that the key in the varipulley is broken and you will have to carefully force the belt off the pulley) Now crank the spindle RPM handle to the highest RPM. This loosens the spindle varipulley Remove the two bolts that hold the motor onto the housing and lift motor up and tilting it slightly. This loosens the belt on the spindle varipulley. I usually rest the motor on the adjusting screw sticking up through the housing. This now gives you enough room to slip the belt off the motor pulley and remove the motor.

#### Easy removal of the head T-bolts or head tilt adjusting Screw

Put and clamp a vise onto the table (If you have a riser block on the machine you may have to block up the vise) Now crank the knee all the way up to the bottom of the head. Position the table with X and Y cranks so the spindle nose goes into the vise jaws Crank the knee up so the bottom of the spindle sets inside the vise jaws Clamp the vise jaws onto the bottom of the spindle. You will see that there is small flat spot underneath the Micrometer rod. I clamp the vise there. You may want to use blocks of Aluminum or wood inside the vise jaws to clamp with. At this point you can loosen the four head T-bolt nuts. Now carefully crank the Y-axis handle and the whole head assembly will go straight out and straight back in again. Be carefull the head assembly is top heavy you may need assistance to balance the head. With it out you can replace the T-bolts (part# 1431), Head tilt adjusting Screw (part# 1097) Head tilt worm gear (part# 1096), on page quill housing You can also replace Quill housing adjusting gear (part# 1186) on page base machine assembly

#### **Replacing bushings and keys inside Motor Varipulley**

With the Spring collapsed on the motor varipulley, I put the varipulley in an Arbor Press. Holding the spring collapsed with the Press (You may need a block to access the bolts) Take out the two 10-32 screws and slowly release the press and the spring Be careful the spring wants to fly up the press handle. Take the spring and the collar off the assembly Take the old Plastic Bushings and key out of the varipulley The bushings should be black, if they are green they cannot be replaced and you have to buy a new Pulley assembly. (part# 1036 for a 2 HP and part# 1037 for a 1 1/2 HP) The pulleys I supply have the replaceable bushings and keys. You will notice inside the bore of the varipulley that there will be some glue left inside This needs to be removed. I use a Dremel type grinder with a drum sander and a Keyway cutter to grind away the glue. The keyway cutter removes the glue inside the groove of the varipulley I clean out the keyway with a screwdriver blade and then run a file in it. Once I've cleaned up the bore, I put the new bushings and key inside the pulley and set it on the motor shaft to see how it fits. If too tight, grind some more glue out. It should be a snug fit. If it fits way to loose the bore may be wallowed out and the pulley replaced Mix up some epoxy (I prefer JB weld the five Minute type) Spread the epoxy on the Bushings and key and set them into the varipulley

No need to glue in the 2HP varipulley key it is held in with a 10-32 screw Quickly set the pulley on the motor shaft and let the epoxy set-up Put the asembly back in the Arbor press and collapse the Spring and collar thread in the two 10-32 screws back on the varipulley so the spring stays collapsed. Put the assembly back on the motor.

On the 2HP varipulley there is a small bore for the 10-32 screw that holds in the key. If it is broken out I countersink a larger bore and put a washer behind the 10-32 screw and reassemble.

All parts can be found on page variable speed upper housing

#### **Replacing Collet Alignment screw inside spindle**

Bring the quill down about two inches

Look on the back side of the quill and you will see a small set screw. Remove it This holds in the nosepiece on the bottom of the quill

With set screw removed you can unscrew the nosepiece. I use an adjustable spanner wrench You will find two holes on the bottom of the nosepiece for this. You may need to use a punch and hammer to get it started.

Right hand thread for Bridgeport mill, left hand thread for Imports.

If the nosepiece does not unscrew this means the threads of the nosepiece are bad You may never get it off without damaging the nosepiece and or quill. It can be very expensive to replace both nosepiece and quill. At this point most people live without the Collet screw and just put it back together

With the nosepiece removed you can get to the Collet Alignment screw (part# 1137) and special socket set screw (part# 1424). You may need to tap on the drawbar to bring the spindle down a bit farther so you can access the Collet screw.

Replace the Collet screw and may need to replace the Special Socket set screw I put an R-8 collet in the spindle and adjust the collet screw by screwing the alignment screw in until it touches the R-8 collet and then back it off so the R-8 collet slides out of the spindle without hanging up.

I use blue Loctite on the collet screw and Special set screw just for insurance Then I tap the spindle back into the quill with a rubber hammer and thread the nosepiece back on. Making sure it is up tight.

There should be a small gap between top of the nosepiece and the bottom of the quill anywhere from .003" to .010". This insures the spindle bearings are seated in the quill. If not check out how to reseat spindle bearings below Before replacing the set screw in the back of the quill, drill a setpoint into the set screw hole.(I use a handrill and a #8 drill) This puts a dimple in the threads of the nosepiece. If you don't you will smash the threads and never be

able to get the nosepiece off again. It also allows the set screw to in farther and not stick out catching on the quill housing.

#### **Spindle Runout**

Use the same disassembly instructions as replacing the Collet Alignment Screw above. When you get the nosepiece off. Take the Drawbar out of the top and put at least a foot long rod about an inch in diameter in place of the drawbar.

Tap on the rod at the top and the complete spindle assembly falls out of the quill. I put a block of wood on the table so when it falls out it bangs on the wood and not the table

Now crank the knee down and Y-axis back so you can get the spindle out. At this point keep everything clean, don't get dirt into the bearings Looking at the spindle assembly you will see that there is a pair of precision thrust bearings with a two inch spacer in between, then there is a long spacer with another precision bearing, on top of that there is a spider washer and a spanner nut. If the short spacer is loose between the thrust bearings you will have runout. To tighten, find a tab on the spider washer that is bent into the spanner nut. bend it back down and out of the way. I clamp the spindle at the splines in a bench vise I use blocks of Aluminum or wood to clamp on in the vise jaws so not to crush the splines Tighten the spanner nut on top of the spindle. I use an adjustable spanner wrench or you can use a punch and hammer. Tighten until it will tighten no more. Adjust or tap with a hammer the small spacer between the thrust bearings so that it will align between the two thrust bearings exactly. I use a six ruler to check the concentricity. If the spacer sticks out to one side or another you'll still have runout. Once you have adjusted the spacer then bend the spider washer tab back into the spanner nut Before putting the spindle back in the quill look up into the quill and you will see a felt washer (part# 1164) in the top part of the quill. The spindle has to go back up through the hole in that felt washer. Be sure to get it through the hole or it will damage the felt washer. The washer is there to keep dirt from getting into the spindle. Now replace the spindle into the quill. After the spindle goes through the felt washer you will feel the splines of the spindle engage the splined gear hub. Just move the spindle around until they mesh together and the spindle goes all the way up. I have found that sometimes the top of the spindle has mushroomed out from years of use of the the drawbar being tigthened. If that is the case you may need to clean up the splines with a file at the top of the spindle. It may also be difficult to get the spindle out because of this Tap on the spindle with a rubber hammer until the nosepiece engages the quill. Tighten the nosepiece with the same instructions as assembling the collet screw above.

#### Adjusting the quill downfeed

After years of use your quill downfeed lacks power and slips. You hear a clicking noise On the left side of the quill you see a round cover. It has a black "S" shaped arm out of it Take out the two long 10-32 screws that holds this round cover in place There you have the quill downfeed clutch assembly. You notice there is a spring with a collar You are suppose to tighten the spring to adjust the clutch but this rarely works What I do is take out the two small pins that holds the "S" shaped black arm on the clutch assembly. The "S" shaped black arm is made of brass. The less "S" there is, the tighter the quill feed is I put the "S" arm in a vise and gently clamp on the brass arm. This takes some of the "S" out I usually do a gentle clamp with the vise the first time. Then reassemble the clutch and try it out. I test it by engaging the quill feed and pulling down on the quill handle. It should have some give and you will hear some clicking of the clutch but should have power enough to put a drill into your part. You can be your own judge. If I still don't have enough power I clamp the "S" arm a second time. I've had some that did this procedure 10 times until I got the right amount of power. Things to watch for. If you straigthen it out to much you'll find that you will have a clicking noise and feel when the quill feed is not engaged. Then you have gone to far Then I put the "S" arm in the vise and clamp on the O part of the arm and use an adjustable wrench to bend or put more "S" back in it. Another thing to be careful with is there is two tabs that stick out from one end of

the arm be careful not to bend or brake these off. If all else fails you can purchase a arm (part# 1388) Overload clutch trip lever - quill housing assembly

#### Adjusting the quill feed tripout

Adjusting the quill feed that doesn't trip out when engaging the Micrometer stop Looking at the front of the quill you see a Micrometer rod. At the bottom of it, there is a trip lever (part#1033-02). You have to look under boss that the micrometer rod goes through. On that lever there is a small set screw. Adjusting the set screw gives more or less trip out depending which way you thread in the set screw. Sometimes you will find the Trip lever all loaded up with chips and you have to take it out and clean it up. There is a small pin that holds it in place. Make sure the micrometer rod is loose. I spray WD-40 on it.

## Replacing a broken Ball trip lever at the top of the Micrometer rod

All I can say is good luck!!

The first piece usually comes out easily. I use a small screw or tap and thread into it and pull it out. You will use profanity on the back piece. Sometimes you can use a small magnet to get it out. Usually I get it out by blowing air around the top of Micrometer rod and moving the micrometer rod around at the same time and it pops out. I have worked on some for hours never getting it out and giving up. (part# 1033-03) on page quill housing

#### Adjusting the clutch arm on a Bridgeport power feed

When you engage the power feed it makes a rattling sound, especially when in rapid and you change directions. Two gears are not engaging and they make the sound. Take the cover off the front of the power feed gearbox. It usually has the name Bridgeport on it. Be ready there is about a half a cup of oil in it. So have a pan ready to catch it so it's not all over the floor. Also have some shop towels handy. Looking in the gearbox you will see a spring attached on one end to the gearbox housing and the other end to the clutch arm. Take the spring loose from the clutch arm. There is a 1/4-20 shoulder bolt that holds that clutch arm in. Undo the bolt and get the arm out. On the clutch arm you will see two roller cams. One on the end that the spring was attached the other back cam engages two gears inside the box. Notice the back cam is in a slot on the clutch arm It usually backs off and doesn't let the two gears mesh in together. I take the back cam off and then mill the slot a little farther to the left so when I reassemble the clutch arm it keeps the the two gears together. I then drill and tap a 6-32 hole in the edge of the clutch arm. This way when I put the roller cam back on the clutch arm I put the 6-32 set screw in so it pushes the roller cam to the left and never backs off again. Reassemble the clutch arm and put it back in with the shoulder bolt. Attach the spring on the clutch arm and put the cover back on. Put about a half a cup of heavy oil, preferably 90 weight in the gearbox through the set screw in the top.

#### **Replacing Cam Ring Pins on Step Pulley Head**

If you have trouble getting a step pulley head to go into back gears. Most times the Cam Ring Pins (Item #10 part #1109) are stripped and need to be replaced. There is not much to replacing the pins, but one thing to look for is not only are the Pins stripped but the Spindle Pulley Bearing Sleeve (Item #11 part #1128) that the pins screw into may also have stripped threads. Get up on the machine table and look down at where the Pins screw into the Bearing sleeve. You will see a couple of small set screws that screw into the Cam Ring Pins and hold them in place. Look off around 30 degrees and you will see another set of holes for those set screws. Bridgeport drilled another set of holes in the Pulley sleeve. Just take the old pins out and rotate the pulley sleeve with a spanner wrench or a punch and hammer and put in the new Cam Ring Pins.



- #1 1270- Screw
- #2 1303- Washer
- #3 1304- Pinion
- #4 1305- Shaft Sleeve
- #5 1306- Bushing
- #6 1307- Set Screw
- #7 1308- Spacer
- #8 1309- Worm Gear
- #9 1310- Worm Shaft
- #10 1311- Shaft
- #11 1179- Key
- #12 1222- Set Screw

#13 1317- Engage Pin #14 1318- Cradle #15 1254- Set Screw #16 1319- Throw-out #17 1320- Shift Sleeve #18 1326- CAp Screw #19 1299- Plunger #201300 Spring #21 1297- Shift Crank #22 1295- Roll Pin #23 1259- Black Plastic ball #24 1361- Shift Crank #25 1363- Cover #261357- Shift Rod #27 1358- Set Screw #28 1360- Shift Fork #29 1303- Locknut #30 1314- Washer #31 1316- Bevel Gear #32 1315- Key #33 1337- Feed Gear #34 1338- Key #35 1339- Input Shaft #36 1340- Drive Gear #37 1341- Bearing #38 1346- Lockscrew #391345- Set Screw #40 1329- Gear Assy #41 1328- Bearing #42 1330- Key #43 1331- Key #44 1332- Shaft #45 1333 Snap Ring #46 1334- Bearing #47 1335- Spacer #48 1336- Plunger #49 1348- Bushing #50 1349- Rev Bevel Gear #51 1350- Rev. Clutch #52 1347- Washer #53 1344- Bushing #54 1343- Shaft #55 1342- Bushing #56 1356- Pin #571355 Pin #58 1359- Key

#59 1354- Worm Shaft #60 1353- Roll Pin #61 1120- Clutch Rod \$14.10 #62 1030- Knob Assy #63 1165- Scale #64 1434A- Upper Screw #65 1434B- Lower Screw #66 1033- Microscrew #67 1451- Plunger #68 1033-03- Trip Ball Lever #69 1452- Lever Screw #70 1438- Stop Knob #71 1439- Cap Screw #72 1053- Quick Nut #73 1033-02- Feed Trip Lever #74 1426- Key #75 1427- Trip Lever Pin #76 1431- T-Bolt Assy #77 1433- Locknut #78 1432- Bolt Spacer #79 1200- Washer #80 1096- Worm Gear #81 1097- Adj. Worm Shaft #82 1453- Set Screw #83 1112- Clock Spring #84 1448- Hub Sleeve #85 1021- Quill Handle #86 1429- Quill Lock Bolt #87 1428- Lock (tapped) #88 1430- Lock (untapped) #89 1151- Lock Handle #90A 1272- Oiler Tube #90B 037-0246- Oil Tube #91 1442- Spring Pin #92 1445- Key #93 1440- Shaft #94 1124- Hub Screw #95 1138- Clutch Spring #96 1449- Pinion Gear #97 1139- Overld Clutch #98 1376- Clutch Sleeve #99 1381- Snap Ring #100 1140- Clutch Ring #101 1377- Washer #1021378- Screw #103 1386- Worm Gear

#104 1385- Gear Spacer #1051384- Shaft Bushing #106 1108- Spring #107 1383- Spring Plunger #108 1374- Brass Plug #109 1375- Clutch locknut #110 1372- Clutch Ring #1111371 Clutch Ring Pin #112 1389- Clutch Washer #113 1390- Snap Ring #114 1388- Trip Lever #115 1399- Set Screw #116 1404- Spring Screw #117 1403- Spring #118 1402- Steel Ball #119 1401- Handwheel Clutch #120 1393- Locknut #121 1392- Set Screw #122 1370- Cap Screw #123 1391- Cover #124 1413- Handwheel #125 1406- Sleeve #126 1387- Dowel Pin #127 1405- RollPin #128 1394- Cam Rod #129 1408- Spring #1301407- RollPin #131 1409- Trip Plunger #132 1410- Bushing #133 1411- Bushing #134 1412- Trip Plunger #135 1395- Trip Handle #1361397 Bracket #137 1195- Cap Screw #138 1435- Screw #139 1164- Felt washer #140 1415- Quill Skirt #141 1420- Nose Piece #142 1425- Quill #143 1454- Quill hosing N/A #144 1424- Set Screw #145 1137- Collet Screw #146A 1414- R/8 Spindle #146B 1414A- Spindle Assy #147 1416 Locknut #148 1417- Lockwasher

#149 1418- Upper Bearing #150 1419- Sleeve #151 1422- Bearing Set #152 1423- Bearing Spacer #153 1421- Dirt Shield #154 1351- Set Screw #155 037-0248- Indicator Rod #156 037-0249- Screw #157 037-0250- Jam Nut



#1 1188- Snap Ring #2 1199- Pivot Pin #3 1201- Bolt

#4 1200- Washer

#5 1195- Cap Screw #6 1186- Gear #7 1196- Roll Pin #8 1187- Ram Adapter #8A 1187A- Scale # 1250- Stop Brkt # 1251A- Stop Pin # 1502- Cap Screw #9 1198- Rivet Screw #10 1192- Shaft #111286-01- Worm Key #12 1191- Washer #13 1190- Gear #141197- Angle Plate #15 1245- Ball #16 1159- Handle #17 1249- Pinion Screw #18 1244- Pinion #19 1129-02- Clamp tapped #201129-01 Clamp Untapped #21 1129-04- Clamp Bar #22 1247- Split Pin #23 1129-03- Stud #24 1194- Ram N/A #25 1246- Turret N/A #261248-Locking Bolt #27 1243- Spider #28 1148- Stop Screw #29 1202- Table N/A #30 1211- Saddle N/A #31 1205- Hex Nut #32 1204- Table Lock #33 1203- T-Bolt #34 1208- Cap Screw #35 1209- Bracket #36 1153- Wiper Plate #37 1154- Wipers #38 1152- Screw #391602-Full Length Wiper #40 1217- Knee 12" N/A #41 1156- X-Gib #42 1157- Y-Gib #43 1158- Knee Gib #44 1106- Gib Screw #451122 Lock handle #46 1206- Lock Bolt

#47 1219- Plunger #48 1207- Plunger #49 1219- Plunger #50 1220- washer #51 1221- Binder Plug #52 1223- Set Screw #53 1222- Set Screw #54 1218- Shaft #55 1175- cap Screw #56 1163- Knee Wiper #571212 Left Holder #58 1214- Right Holder #59 1241- Pedestal N/A #60 1239- Column N/A #61 1166- Jam Nut #62 1224- Hex Nut #63 1225- Washer #64 1226- Bevel Gear #65 1171- Cap Screw #66 1228- Retainer Ring #67 1227- Bearing #68 1227A- Bearing Sleeve #69 1071- Elevating Screw #70 1072- Elev. Nut #71 1242- Cap Screw #72A 1236A- Elev. Shaft #72B 1236B- Elev. Shaft 9" #73 1179- Key #74 1145-02- Crank Handle #75 1145-01- Elev. Crank #76 1230- Clutch Insert #77 1168- Dial Lock #78 1232- Dial Holder #79 1231- Dial #80 1172- Bearing Ring #81 1178- Bearing #82 1235- Bearing Cap #83 1238- Set Screw #84 1237- Bevel Pinion # 1215- Upper Guard # 1216- Lower Guard #85 1096- Worm Gear #86 1097- Worm Shaft



Important: Be sure to check if you have a 2 HP or 1-1/2 HP motor. There are a difference in parts like Bushings, Keys, Pulleys, and Belts

Motor parts are available please e-mail request

Prices subject to change without notice

#1 1459- Chip Shield
#2 1460- Screws
#3 1603- Block
#4A 1455A- 1-1/2HP Dial
#4B 1455A- 2HP Dial
#5 1463- Bushing
#6 1464- Stud
#7 1465- Chain
#8 1462- Roll Pin
#9 1488- Chain Drum

#10 1487- Spur Gear #11 1457- Set Screw #12 1461- Bronze bearing #13 1348- Bronze Bearing #14 1132-03- Hex Nut #15 1478- Face Plate #16 1477- Cap Screw #17 1458- Housing #18 1480- Cap Screw #19 1472- Bronze Bearing #20 1356 Roll Pin #21 1343- Worm gear #22 1472- Bronze Bearing #23 1307- Set Screw #24 1473A- Shaft #25 1479- Set Screw #26 1471- Wave Washer #27 1476- Handwheel #28 1475- Caution Plate #29 1474- Handle #30 1026- Drawbar \$21.75 #31 1544- Cap Screw #32 1195- Cap Screw #33 1468- Bearing Cap #34 1466- Drum Switch #35 1552- Cotter Pin #36 1555- Washer \$2.20 #37 1545- Jam Nut #38 1553- Pivot Stud #39 1469- Cap Screw #40 1548- Screw #41A 1546- Motor 1-1/2 HP #41B 1547- Motor 2 HP #42 1467- Belt Housing N/A #43 1105- VariSpeed Belt #44A 1115 Timing Belt #44B 1536- Timing Belt #45 1564- Spacer #46 1573- Key #47A 1117- Hub 1-1/2 HP #47B 1537- Hub 2 HP #48 1543- Snap Ring #49 1508- Wave Washer #50 1542- Bearing #51 1489- Pulley Sleeve #52 1560- Snap Ring #53 1556- Pivot Sleeve #54 1554 Cap Screw #55 1551- Plate #56 1557- Bearing Housing #57 1559- Adj. Varidisc #58 1558- Bearing #59 1126- Bushing #60 1095- Key #61A 1113- Bushing 1-1/2 HP #61B 1114- Bushing 2 HP #62A 1035B- 1-1/2 HP Key

#62B 1035A- 2 HP Key #63A 1037- 1-1/2 HP Varidisc includes key, bushings, spring and collar #63B 1036- 2 Hp Varidisc includes key, bushings, spring and collar #64A 1571- Snap Ring 1-1/2HP #64B 1599- Snap Ring 2HP #64C 016-0070- Ret. Ring CNC #65 1307- Set Screw #66A 1567- Pin (1-1/2 HP Key) #66B 1407- Pin (2 HP Key) #67A 1568- 1-1/2 HP Key #67B 1597- 2 HP Key #68A 1569- 1-1/2 HP Varidisc #68B 1598- 2 HP Varidisc #69A 1546-01- 1-1/2 HP Shaft #69B 1547-01- 2 HP Shaft #69C 1547-03- Motor Shaft CNC #70 037-0113- Link #71 1311- Key # 1582- Lube Data Plate